

# Blade Change for Aluminium Ratchet Secateurs No. 4363



## Tools Required

1. Small flat blade screwdriver
2. Small Hammer
3. Blade replacement kit (blade, allen key, pin, 2 clips, rivet)



1. Remove the ratchet pin clip by levering up the edges with a small screwdriver (note: the clip is not to be used again)
2. Remove the ratchet pin by pushing it down



3. Undo the centre retainer bolt using the allen key supplied with blade kit, remove the bolt



4. Hold the blunt edge of the blade and pull it forward to remove the blade
5. Clean and lightly lubricate all parts before installing a new blade (we recommend INOX)



6. Insert the new blade and tighten the bolt with the allen key
7. Insert the new ratchet pin supplied with the blade kit



8. Place a thin support base under the head of the ratchet pin to stop it moving
9. Place a clip on the the pin and push down hard with your thumbs on the opposite outside edges of the clip to get it started onto the ratchet pin



10. Use the supplied rivet and a hammer to tap down the clip



11. Ensure the clip is on the groove in the ratchet pin. Keep the allen key and all spare parts for future use